


Instructions On WINPAL Printer Testing Tools

I. Introduction of Main Interface



The screenshot shows the Winpal Printer software interface with the following numbered components:

- Port Select:** Radio buttons for LPT, COM, **USB** (selected), and NET.
- Printer Type:** Radio buttons for WP-58, WP-76, and **WP-80** (selected).
- LPT Settings:** A dropdown menu currently showing **LPT1**.
- COM Settings:** Fields for COM1, 38400, and RTS.
- NET Set:** A section containing IP address fields (Local IP, Printer IP, New IP), a New ID field, and buttons for Refresh, Auto Set Ip, Connect, Ping, Set New IP, NetMonitor, and New ID.
- Content:** A checkbox for NO. and a numeric input field for Rep: (set to 1).
- HEX:** A checkbox for hexadecimal output.
- AutoSend:** A checkbox for automatic sending, with a cycle time of 500 ms.
- CutPaper:** A checkbox for cutting paper.
- Print:** A button to initiate printing.
- Cut Paper:** A button to cut the paper.
- Open cash drawer:** A button to open the cash drawer.
- Traditional:** A button for traditional printing mode.
- Driver Print:** A button for driver printing.
- Advanced:** A button for advanced printing options.
- 中文简体:** A button for simplified Chinese language.

The interface also includes a status bar at the bottom with the text "Status Bar: Real-time display of print status!" and a footer with the Winpal logo, company name "Guangzhou Winprt Technology", website "www.winprt.com", and copyright information "Copyright (C) WINPAL".

1. Communication port selection:

Four options of printer communication interface: parallel port, serial port, USB port and Ethernet port.

2. Printer type selection:

Printer type: default to WP-80

3. Parallel port Settings (LPT Set):

Parallel port Settings ----be consistent with the computer communication parallel port number.

4. Serial port Settings (COM Set):

Serial port Settings ---- set the serial port number, baud rate, flow control, etc.

5. Ethernet port Settings (NET Set):

Change the IP address of Ethernet port printer through Ethernet port Settings.

“Local IP” --- computer’s real IP address which can be added manually or by Clicking "refresh" button.

“Printer IP” ---printer’s current IP address , its detailed information can be seen on self- test page, only suitable for Ethernet port printers.

“New IP address” --- the new IP address the printer’s IP address is to be changed to (printer’s IP address shall be in the same network segment as the connected computer’s to realize intercommunication).

“New ID address” --- the new ID address the printer’s ID address is to be changed to(Printer’s ID address must be an only address within a network).

Ethernet port settings are operated by means of HUB and SWITCH, in case that the settings can’t bechanged by ROUTER, other means can be used, please refer to the PDF in the folder "IP address changes. and other functional specification" on the CD.

“Auto Set IP” ----Used to search printers in the same LAN

“Net Monitor” ----Monitor printer status through network. (net port available)

6. Number of the copies:

It refers to the printing quantity of the repeat print of the test content.

7. HEX:

Data can only be transmitted by inputting hexadecimal after having selected printing content. (It’s mainlyused to send instructions to the printer).

8. Printing content:

Edit the printing content here, and send data by clicking "Print" button.

9. Automatically sending, cycle, paper cutting:

“Automatically sending”----- Click the "Auto Send" button and the software will automatically send the data in the printing content column to the printer.

“Cycle” ----- cycle time to send data automatically

“Paper cutting” ----- Printer will automatically do paper cutting work according to the cycle time after the “Auto Send ” button and “cyc” botton have been set.

10. Print:

Print the information and data in the “content”edit box.

11. Paper cutting:

Test the function of paper cutting action.

12. Open cash drawer:

Test the cashbox function

13. Traditional font test:

Used for testing traditional fonts printing

14. Driver print:

Call the installed Windows driver to test print, printing out the information suggests successful installation

15. Advanced:


Click "advanced" button, and set up more features to have print test, below is the detailed introduction.

16. English:

It's for switching software interfaces between English and Chinese.

II. Setup instructions for "advanced" button

Click the "advanced" button on the main interface, the following interface will pop up:



The screenshot shows the 'Advanced' settings window with the following settings highlighted by numbered red boxes:


- H Parameter Settings: 1
- Code page Settings: 2
- NV Logo Test: 3
- Barcode Printing test: 4
- P76 Buzzer Settings: 5
- P76 Density Settings: 6
- P80 Black sens: 7
- baud rate settings: 8
- DIP Settings: 9
- 2D Barcode test: 10
- Net Settings: 11
- USB MODE Settings: 12
- Black Mark Settings: 13
- File data send: 14
- Cut With Beep: 15
- InputBox Codepage: 16

1. Set H parameter:

Its Main function is for definition adjusts of the 76 series needle printer. First click "Print H", and the printer will print 16 groups of H letters from 0 to F, then set "Set delta" button by choosing the clearest Group.

2. Set Code page:

It's for changing the default printer code page. Following is part of the code pages of the 80 series machine,




Code Page:	
0:PC437(Std.Europe)	1: Katakana)
2:PC850(Multilingual)	3:PC860(Portugal)
4:PC863(Canadian)	5:PC865(Nordic)
6:(West Europe)	7:(Greek)
8:(Hebrew)	9:(East Europe)
10:(Iran)	16 (WPC1252)
17:PC866(Cyrillic#2)	18 PC852(Latin2)
19:(PC858)	20 (IranII)
21:(Latvian)	22 (Arabic)
23:(PT1511251)	24 (PC747)
25:(WPC1257)	27 (Vietnam)
28:(PC864)	29 (PC1001)
30:(Uigur)	31 (Hebrew)
32:WPC1255(Israel)	255:(Thai)

Input the desired parameter value in "Set code page", and then complete the setting by clicking "set code page" button. Click "print code page" button to view the setup code.

3. NV logo demo:

Click the "NV download" button, the menu below will pop-up:



3.1 Size requirement and function selection of paper cutting of NV LOGO printing.

3.2 Open LOGO:

Click and select BMP format picture or the LOGO file that you want to print.

3.3 Download NV LOGO:

Click the download button after opening the BMP format file and the file will be downloaded to the printer. Print the file content by clicking "print LOGO" button.

3.4 Print LOGO:

Click this button to complete the LOGO image printing.

3.5 Clear LOGO:

Remove the downloaded NV LOGO.

3.6 Mult NV LOGO down.

3.7 Show current NV LOGO

4. Barcode printing test:

Choose a variety of barcode types and height to test the print with a total of nine kinds of one-dimensional code choice.

5. P76 Buzzer Settings:

It's a setting for turning on or off the beeper for part of the 76 series machines.

6. P76 Printing density Settings:

To adjust the printing effect of 76 series machine, there are modes: LIGHT、NORMAL、DARK.

7. P80 Black mark sensitivity Settings:

The adjustment of black mark sensitivity Settings for 80 series machines according to different black mark paper. Valid only when black mark function set is on.

8. Serial port baud rate Settings: (only for 58 series and P76E machines)

To set different baud rate (such as: 9600, 19200, 38400, etc.)

9. DIP switches Settings:

Threemodes:58series,80series(onlyformachineswithoutdialswitches)

P58 DIP Settings

Select cutter
☒ OFF ☐ ON

Cutter mode
☒ Partial ☐ Full

Print density
☒ Light ☐ Dark

Select beeper
☒ No ☐ Yes

Cutter with drawer
☒ No ☐ Yes

Set

(58series)

P80 DIP Settings

Select cutter
☒ YES ☐ NO

Select beeper
☒ YES ☐ NO

Print density
☒ Set(1-8) ☐ default

Chinese mode
☒ YES ☐ NO

Character per line(FontA/B)
☒ 48/64 ☐ 42/56

Cutter with drawer
☒ NO ☐ YES

Serial baudrate
19200

Set

(80series)


10. 2D barcode testing:

Edit and print test of two-dimension codes



11. “Network Settings”

It includes "Network Settings" and "Bluetooth Settings"



(Network Settings)

“1” Set up the Printer’s IP address.

“2” Set up the Subnet Mask.

“3” Set up the Gateway.

“4” WIFI SSID address settings. Note: the SSID address is the name of your Wireless Router’s name.

For example, if the address of the current Router (SSID) is: Pinter001, then this SSID address should be typed in the tab of “SSID”.


“5” WIFI password settings. Note: the password of the Wireless Router

For example, if the WIFI’s current password is:123456789, then this password should be typed in the tab of “WIFI password”.

“6” Encryption type of WIFI SSID settings. Note: the encryption type of the Wireless Router.

For example, if the encryption type of the Router (SSID) is: WPA_TKIP_AES_PSK, then this information should be selected in the tab of “SSID Encryption type”.

“7” After filling the above information, click the “Setting All” option. The printer will “BEEP”. Next, restart the printer.



(Bluetooth Settings)

“1” Set up the Port name of the Bluetooth Printer (the Factory Default BT NAME is “Printer001”)

“2” Set up the Password of the Bluetooth Printer (the Factory Default BT PINKEY is “123456”)


“3” After finishing the above settings, click “Setting”, and then finished the settings of Bluetooth printer Parameters.

12. “USB Mode Setting”

Mode Setting of printer’s USB port includes Usb Printing and Virtual Com. USB mode switches according to customer demand. For specific operation, refer to file “instructions of switching between USB port and virtual Com ”in the folder “IP address change and other functional specification”

13. “Black mark Settings”

To set special paper printing with black mark.



The screenshot shows the 'BlaceMarkSet' dialog box with the following elements highlighted by red boxes and numbered callouts:

- 1**: Radio button for 'Feed direction' (selected) and 'Back paper direction'.
- 2**: Input field for 'Please enter the notes long(from mark to mark):' with the value '300' and a unit 'mm'.
- 3**: Input field for 'Set The Black Mark Maximum Width:' with the value '10' and a unit 'mm'.
- 4**: Input field for 'Cut tear position to the black mark position' with the value '20' and a unit 'mm'.
- 5**: Input field for 'Print position to cut tear position' with the value '20' and a unit 'mm'.
- 6**: Button labeled 'Print a ticket Test'.
- 7**: Button labeled 'Feed to next start print position'.
- 8**: Button labeled 'Feed to next cutting position'.
- 9**: Two buttons at the bottom: 'Close Black Mark' and 'Open Black Mark'.

13.1 Offset in paper-feed direction, offset in paper unwinding direction

To set the direction of data calculation for paper cutting position, the default value is feed direction.

13.2 "Please enter the black mark spacing (mark length)" To calculate the center distance of two black marks.

13.3 "Set the black mark Maximum width"

It's a value to calculate the actual height of a black mark.

13.4 "the offset of paper cutting position relative to the black mark position"

It's to calculate the actual distance from the paper detector in the print head to the paper cutter.

13.5 "Distance between the print starting position and paper cutting position"

It's to calculate the distance from the print starting position to paper cutting position.

13.6 "Print a ticket test"

Click this button and a note will be printed out. If it's properly set, paper will automatically go a length of black mark and then be cut.

13.7 "feed to next print position"

Click this button and paper will go to the next print starting position for a black marker. Print out the information to test the right position.

13.8 "feed to the next cutting position"

Click this button and paper will go to the next paper cutting position and paper will be cut to test the accuracy of paper cutting position.

13.9 Turn on the black mark, turn off the black mark

Black mark function is off by default. Turn on black mark function to make related Settings. In case black mark position is detected incorrect, please reset referring to 7 "P80 black mark sensitivity" of "advanced".

14. "Send file data"

Click button, choose and open TXT format file in the pop-up dialog box, and then the printer will print the contents of the file.

15. "Cut With Beep"

The alarm function can be set to turn on or off after cutting paper with cutter.

16. "Input BOX Code Page"

Words responsible for decoding text boxes.